

Pan Tilt Bracket



Contents

- 1. WHAT'S IN THE BOX
- 2. ASSEMBLING THE PAN TILT BRACKET
- 3. FULLY ASSEMBLED PAN TILT BRACKET
- 4. MOUNTING THE CAMERA
- 5. LINK CABLE
- 6. GENIE MINI CONNECT
- 7. APP CONNECT
- 8. HOME SCREEN
- 9. TECH SPECS

Please read the instructions carefully before using the Pan Tilt Bracket. For more detailed setup tutorials including 'Pan Tilt Bracket Setup Tutorial' and 'how to setup a Video' tap the question mark in the bottom right of the App or subscribe to our <u>Youtube Channel</u>.



What's in the Box I ltems that are included in the box when you purchase a Pan Tilt Bracket

Assembling the Bracket Attach the Pan Tilt Brackets to the Genie minis.

- Attach the Genie Mini to a tripod head or the tripod legs. If using a tripod head then use the thread adapter included with your Genie mini to tranform the large thread on the Genie Mini into a small thread.
- 2 Unscrew the two sections of your Pan Tilt Bracket and attach the panning section to the Genie mini on your tripod. Make sure to align the markings on the tightening wheel with the icons on the Genie mini, now tighten by screwing the black wheel.
- Attach the tilting bracket to the other Genie mini by lining up the markings again.
- 4 Attach the tilting Genie mini to the panning bracket already attached to the tripod.



Fully Assembled Bracket | The Pan Tilt Bracket correctly assembled with Genie minis.

- Fully assembled Pan Tilt bracket. Note the two bracket section markings are aligned with the Genie mini icons.
- The tilt bracket is also level. It is important that your camera starts with a level tilt so it works correctly with the App.



Mounting the Camera | Attach your camera to the assembled Pan Tilt Bracket

Attach your camera to the tilting bracket, you can adjust the mounting thread so that the camera and lens weight is centred on the bracket.





Link Cable

The Syrp link cable is used to trigger your camera for shooting timelapse. Refer to our <u>website</u> to find the correct cable for your camera.

- 1 Plug in the 2.5mm end into the camera port on the Genie Mini marked with a green camera icon.
- 2 Plug the other end into the remote port on your camera. Consult your camera manual to find the correct port.
- Once connected the Genie Mini is ready to trigger your camera for timelapse.



Genie Minis up to pair with the Syrp Genie App.



Press the Syrp button for 1-2 seconds on the front of each Genie Mini.



The Bluetooth LED indicator will flash green confirming that the Genie Minis can now be paired with the Syrp Genie App.



App - Connect

Turn ON bluetooth on your device and connect the Syrp Genie App to the Genie Mini.



1 In the settings menu on your device, Turn bluetooth ON.



2 On the Syrp Genie App, navigate to the 'Connection' screen by tapping the Syrp Connect icon at the top right of the screen.



3 Your Genie minis will appear in the list. Connect each Genie mini by tapping on their circle.



A green tick icon will appear linking the panning and tilting Genie minis. The App is now connected.



Home Screen

Choose your recording type.



1 To start a recording select either Timelapse or Video.



2 Tap the Community button to watch films shot with the Genie Mini and other Syrp products.



3 The Question Mark in the bottom right will take you to a selection of video tutorials about various setups.



4 Tap the Settings Cog in the top left to adjust settings on the Genie Mini

Technical information.

DIMENSIONS 1 Length: 195mm Width: 110mm Height: 203mm

PAYLOAD / WEIGHT 2 Payload: 3kg centered (6.6 lb)

Weight: 365g (0.8 lb)

COMPATITBILITY 3 Syrp Genie mini <u>view here</u>

MOUNT TYPE **4** Bracket mounts 3/8"

Camera mount 1/4"

Included 2 x 3/8" to 1/4" adapter

Contact.



Syrp Limited 43A Linwood Ave, Suite 7 Mt Albert 1025 Auckland New Zealand +64 9 845 6319



General enquiries: syrp@syrp.co.nz

www.syrp.co.nz



twitter.com/syrp_



vimeo.com/syrp



<u>instagram.com/syrp</u>



gplus.is/syrp



facebook.com/syrp.co.nz



youtube.com/c/syrp